

SYSTEM COMPONENTS



For all pipe Ø
from 10-42 mm
3/8"-2" Tube (external Ø)
1/4"-3" Pipe (internal Ø)

serv-Clip 1 for mounting on pressurized pipes



Pressure Sensor

serv-Clip 2 for mounting on non-pressurized pipes



Temperature Sensor

Pressure Sensor

Flow rate and Leakage Sensor


Combinated with

Suitcase with mobile measuring system FM-1-B for Q,L,P,T Sensor



Combinated with

For mounting on pipe



Tube connection

serv-Clip provides the basis for



The sensor monitoring and diagnostic system is equipped with a touch-screen based symbol display and ensures optimized maintenance of systems when combined with serv-Clip.

bkm www.servclip.com



Combine different diameters with our service suitcase (Content : 8 pieces)